TalkTalk

Your YouView

user guide

- 70+ of the best Freeview channels
- 7 day catch-up
- The best players on your TV





Sky Sports and Sky Movies with a one month commitment











Dip in and out of Sky Sports and Sky Movies

one month at a time



5 channels for £30 a month Channels 501-505

11 channels for £15 a month Channels 530 - 540

Now included with our Sky Movies Boost

To add instantly go to the channel and press OK



talktalk.co.uk/tvboost

What's inside?

Main features	5-7
YouView Guide	8-11
Browse and search programmes in the YouView Guide	8
Extra channels	11
On Demand	12-15
Catch up on your TV	12
The TalkTalk Player	14
Renting films and adding Boosts	16
Your TalkTalk PIN	17
More information	19-23
Parental controls	19
Settings	20
Troubleshooting	21
Quick connection	23

All information and prices in this guide are correct at time of going to print and subject to change.

Get the most from your YouView box

Access all your favourite Freeview channels

You'll need a working TV aerial to get your Freeview channels. Your YouView box will automatically tune in to the standard channels including some in HD. Your YouView box will allow you to, pause, fast forward and rewind while you are watching.



Connect your box to your TalkTalk router

Get set up to watch BBC iPlayer, ITV Player, 4oD and Demand 5 all on your TV. You'll need to connect your YouView box within 90 days or you may be asked to return it to us.



Use your TalkTalk PIN to watch more

Sign up to our great value Boosts for a month at a time - perfect for the school holidays or the sports season. Rest assured that you'll always be prompted to enter your TalkTalk PIN before you're charged. You'll find it online at talktalk.co.uk/tvpin



✓ Keep your details up to date and never miss out

To hear about the latest box sets and movies just log in to talktalk.co.uk/myaccount, check we've got your details right and sign up for updates.

For more help visit talktalk.co.uk/tvhelp

TIP

You can adjust the Eco-Mode in Settings for a much faster start up time.



Enjoy all this:

- 7 day catch-up from the YouView Guide
- The best players on your TV
- Monthly Sky Sports and Sky Movies with a one month commitment
- The latest blockbusters available to rent



7 day catch-up

Catch up on the last 7 days TV by going backwards in the programme guide. Search, watch, pause and rewind a range of shows on over 70 Freeview channels like Dave, ITV, Channel 4 and Channel 5.



Rent the latest blockbusters

Press TalkTalk on your remote and explore the TalkTalk Player. It's exclusive for TalkTalk customers and where you can rent the latest blockbusters (using your TalkTalk PIN) – many on the same day as the DVD release.



BBC iPlayer and much more

Connect your box to your TalkTalk router to get up to date on thousands of shows from the best Players like BBC iPlayer, ITV Player, 4oD, Demand 5 and Dave, all ready to watch on your TV.



Flexible Boosts available a month at a time

With our great value TV Boosts you can dip in and out of Sky Sports, Sky Movies or our Entertainment Boosts including some of the best entertainment channels like Sky1, Sky Living, FOX and Discovery Channel.

One remote is all you'll need

You can set up your TalkTalk remote to control both your TV and YouView box.

Press (Search) until the TalkTalk button flashes 3 times and stays lit.

Press and hold the number on your TalkTalk remote for your TV brand until your TV switches itself off.

Grundig	1	Samsung	6
JVC	2	Sharp	7
LG	3	Sony	8
Panasonic	4	Thomson	9
Phillips	5	Toshiba	0

After your TV switches off, release the number button.

Switch your TV on again when the button on your remote flashes twice.

If your TV is not one of the 10 brands listed above you will have to manually tune your remote control to your TV. Find out how at talktalk.co.uk/tvhelp.



Main features

You'll find your way to the main features quickly and easily with your remote

Browse the YouView Guide

Find your favourite channels easily all in one place. Press (outs) to access channels including some in HD.

Find extra channels quickly. Press to filter by genre such as Children's, Entertainment or Films or easily find anything you have subscribed to. You can go straight to a channel by pressing the number keys on your remote.

Catch-up on TV from the last 7 days

Browse TV On Demand

Connect your YouView box to your TalkTalk router to catch up on episodes from your favourite series – all ready and waiting for when you are. Press (y) to go to the main menu and use (L) to scroll across to On Demand.











Search for your favourites

Find what you want to watch quickly and easily.

Just press (such) to start looking.




Find what you want to watch

Connect your box to your TalkTalk router to catch up on many programmes that you haven't had time to watch over the past 7 days.


The programme guide lets you catch up by going back in time, so you can watch your favourite shows at a time that suits you.

You'll find your favourite channels available to search, pause or rewind at the touch of a button.



(This schedule is for illustrative purposes only and does not reflect the current schedule.)


See what's available in the YouView Guide



Catch-up

If you've missed something that was on last night or last week, it may be waiting in the YouView Guide ready for you to watch when you want.

ON YOUR REMOTE PRESS:



Search

Search for your favourite films and shows quickly and easily in the YouView guide.

ON YOUR REMOTE PRESS:



Pause, rewind, fast forward

ON YOUR

REMOTE

For up to 30 minutes while watching a programme on one of the Freeview channels.




Plan what to watch, wherever you are

Browse your TV guide and set reminders with our free TalkTalk TV App on your Android phone, when you are out and about. It's easy to download, just visit the Google Play Store and search for 'TalkTalk TV'.

TO LOG IN:



TO CREATE A WATCH LIST:



with only one month commitment it's easy to try them all out!



See our TV Boosts at talktalk.co.uk/tvboost

To add instantly go to the channel and press

Extra Channels

Search and add some of the UK's most popular channels to your package, a month at a time. Enjoy shows from the best entertainment channels including Sky 1, Sky Living, Sky Movies, Sky Sports, Fox, Watch, Comedy Central, Discovery and many more. You'll quickly find them listed in the YouView guide from channels 401-599.

Search

Search for your favourite premium entertainment easily. Look for the channels with three blue dots under the number

ON YOUR REMOTE PRESS:



To run through the complete listings

already subscribed to

Add channels

Use your remote to easily and securely add channels to your package.

ON YOUR REMOTE PRESS:

Type in the channel number on your remote to jump straight to it

To select. You will be prompted to enter your TalkTalk PIN before you are charged for anything

Hide channels

Hide channels so you'll easily find your favourites.

ON YOUR REMOTE PRESS:



To bring up the YouView Guide



Enter your YouView PIN



Go to the channel you want to hide



X will appear to show the channel is hidden



To save changes

Catch up on your TV


Connect your box to your TalkTalk router and catch up on past episodes of your favourite series.

You'll be able to choose from a selection of TV, films and music from BBC iPlayer, ITV Player, 4oD, Demand 5 and Dave all on your TV.

With more Players being added all of the time there will always be something for the whole family to enjoy.



Accessing the On Demand libraries



Browse by type of content

Lets you browse all of the entertainment across the Players by categories such as Romantic Films or Kids TV.


ON YOUR REMOTE PRESS:



Search

Search through the On Demand libraries for your favourite films and shows.

ON YOUR REMOTE PRESS:






Browse by type of content

When you are in the Talk Talk Player you will see all of the entertainment like Kids, Factual, Film and Sport across the top of the screen. Underneath there will be highlights.

REMOTE PRESS:



Channel hop

There are lots of ways to discover what else is on while you are watching something in the TalkTalk Player.

Pause, rewind and fast forward

For up to 30 minutes while watching a film or show in the TalkTalk Player.

ON YOUR



To exit the TalkTalk Player and watch that channel

REMOTE PRESS:

To pause what you're watching To continue watching the \triangleright programme from where you left off To rewind and fast forward To choose a different amount of time to jump forwards or backwards To jump backwards or forwards

Renting films and adding flexible Boosts

Rent films for up to 48 hours or add premium channels to your package with only a one month minimum commitment.

With our great value TV Boosts you can dip in and out of Sky Sports, Sky Movies or our Entertainment Boosts including some of the UK's best channels including some of the best entertainment channels like Sky 1, Sky Living, Fox, Discovery Channel and many more.

Rent the latest blockbusters

Renting a film is simple and secure. What you've paid to watch will be clearly shown on your bill and you will always be asked to confirm your purchases using the TalkTalk PIN, so nothing can be bought by mistake.

Add a Boost

Add TV channels instantly to your package using your remote. Type in the channel number and follow the on screen instructions (remember to have your TalkTalk PIN handy). Don't be afraid to explore, it doesn't cost anything, so make sure you have a good look around.

*You'll need to have a minimum broadband speed of 5Mb in order to add TV Boosts.







Your TalkTalk PIN

This provides you with a simple and secure way of purchasing entertainment - you'll find yours online at talktalk.co.uk/ myaccount. For extra security if you forget your PIN or want to change it you can do this easily by logging into My Account and following the step by step instructions.





Renting films

Select the film you want to watch

You'll be taken to the payment screen where you'll see what options are available, for example you can purchase a film on a one-off basis or you may prefer to add it to your package as a Boost and pay monthly.

You can keep anything that you've rented for up to 48 hours and can watch it as many times as you like within that period.

The price is shown on screen and **you'll only be** charged when you enter your TalkTalk PIN.

Enter your TalkTalk PIN when prompted.

As soon as you enter your TalkTalk PIN the film or show will start and you will see the charge on your next bill.

Flexible Boosts

We have a wonderful selection of great value kids, sports and entertainment Boosts that you can add to your package with just a one month minimum commitment - you can remove them anytime after that.

Add Boosts to your package quickly and easily with your remote control. They'll be active on your account straightaway - this is ideal for watching the latest movies or sports.



Add or remove Boosts online at

talktalk.co.uk/mvaccount where you'll also be able to see a list of all the Boosts available. If you add Boosts through My Account they can take up to 24 hours before they become active.

You can easily find anything that you have subscribed to in the YouView Guide. Just press to filter the channels and search through them quickly.

Parental controls

Here at TalkTalk we take safety very seriously and understand that you can't always be in the room to monitor what your children are watching. With Parental Controls you can choose which programmes are restricted, with peace of mind that any unsuitable programmes are PIN protected.

Use your YouView PIN to protect children by limiting access to what they can see by age rating. This is different to your TalkTalk PIN which is used to rent films and shows and buy Boosts in the TalkTalk Player.

Your YouView PIN - protect children from seeing anything inappropriate

Your YouView box comes with a YouView PIN (1234) already set. We recommend that you change this to make it more secure. You may want to make it the same as vour Talk Talk PIN which is used to rent films and shows in the Talk Talk Player and buy Boosts, so you've got less things to remember.

Manage your parental controls

ON YOUR REMOTE PRESS:



To go to the main menu




Scroll across to Settings



Select Parental Controls and follow the instructions on the screen

To hide adult content so it can't be seen in On Demand.

ON YOUR REMOTE PRESS:







Select Parental Controls



Select Restrict Adult category





one month at a time





























See our TV Boosts at talktalk.co.uk/tvboost

To add instantly go to the channel and press

Manage your YouView settings

You can change any of your YouView settings at any time to personalise your TV experience. To access any of the options covered in this section, press (\mathfrak{I}) and select Settings, then use the \triangleleft to move backwards and forwards through the menu options.

Changing Languages

The default language is English. If you would prefer to hear a programme in a different language, you can change your language settings.

ON YOUR REMOTE PRESS:



To get to the main menu



Go to Settings select Language to change your audio or subtitle languages

Re-tuning

Occasionally, you may need to re-tune your live digital TV channels. For example, you may have moved house or you could be experiencing problems with your reception.

ON YOUR REMOTE PRESS:

Make sure your aerial is connected

Go to **Settings** and select TV Signal & Quality

To get to the main menu

Select Re-tune Channels to begin the re-tune

Synchronise picture and sound

Connecting your YouView box to speakers or a surround sound system may cause syncing issues. If this happens, you will need to adjust the audio delav.

ON YOUR REMOTE PRESS:



To get to the main menu



Scroll across to Settings



Select TV Signal & Quality



Select Synchronise Picture & Sound



Use the left or right arrow keys to select the correct audio delay

Troubleshooting

1. Setting up

When you switch your YouView box on for the first time, you'll need to run through the set up wizard to tune the TV channels available to you. If the set up wizard doesn't start, freezes or the 'All Done' screen is not displayed at the end, try the following steps to resolve this:

- a) Check the power cable is connected securely to your YouView box and power is switched on at the wall.
- b) Check your TV is ON and not in standby.
- c) Press INPUT or SOURCE on your TV remote control and check your TV display reflects the input YouView is connected to (e.g. HDMI).
- d) If the set up wizard has frozen, check your aerial cable between your TV and YouView box and also your ethernet cable between your box and router are connected correctly and securely. If not, re-connect any loose cables. If you have used Powerline Adapters, check these cables too.
- e) Restart your YouView box. Press the On/Off switch at the back of the YouView box, then press the I/O button at the front. The set up wizard should restart.

If the set up wizard has finished but your YouView box did not connect to your broadband, try the following steps to resolve this:

a) Press the (\mathfrak{V}) button on your remote control, go to Settings > Network & Internet > Wired Connection and select Automatic. This should enter your broadband settings for you automatically. If this does not happen, restart your router and try again. If you need to enter values manually, select Manual.

b) If you did not accept the Terms of Use at the end of the set up wizard, you will not be able to use the On Demand or Search features. To change this, press (5) on your remote control and go to Settings > Your Info & Legal > Terms of Use. Select Accept then press OK. The On Demand and Search features should now be available to you.

2. Poor picture - Freeview channels

If your picture is pixelated or breaking up: This is likely to be a problem with the signal reaching your YouView box. Try the following aerial signal steps to resolve this:

- a) Check all your cables are connected correctly and securely. In particular, check your aerial cable's connection to the wall socket and your YouView box.
- b) Restart your YouView box. Press the On/Off switch at the back of the YouView box, then press the I/O button at the front.
- c) If restarting your box didn't fix the issue, try a channel re-tune. Using your remote control, press the YouView button, go to Settings > TV Signal & Quality > Re-tune Channels.
- d) Have there been any recent changes in or outside your home? For example, have you placed any electrical appliances near the YouView box? Is there any building work taking place or has there been any extreme

weather? These can sometimes cause electrical interference with your equipment. Try moving any electrical appliances away from your YouView box to see if this helps.

e) You may need to contact an aerial engineer if the problem persists as the quality of your home aerial may not be sufficient. You can find more details about this at talktalk.co.uk/tvhelp

3. Poor picture - On Demand

If you experience buffering, jittery or frozen picture whilst watching On Demand or Catch Up, try the following:

- a) Check to see if there are any other devices connected to the internet e.g. laptops or games consoles. These can slow your broadband speed, especially during peak periods. Disconnecting or reducing usage of these devices may resolve this issue.
- b) Check that all your cable connections, in particular the ethernet connection from your YouView box to your router or Powerline Adapters, are connected correctly and securely. If not, re-connect any loose cables, restart your router and turn the power OFF and then ON to reset Powerline Adapters.
- c) If the problems persists, you may need to contact your broadband provider or an engineer. For more details, visit talktalk.co.uk/tvhelp

22

4. Sound problems: no sound

If you can't hear anything, try the following:

- a) Check whether the mute or volume control button on your TV and / or YouView remote control have been accidentally pressed.
- b) Check all your HDMI / SCART cables are connected securely.
- c) If connected to a surround sound system, check that the system is ON and cables are connected correctly and securely.

Syncing between picture and sound If you have connected your YouView box to a surround sound system, you can adjust the synchronisation between the sound and picture manually. To do this, press (5) on your remote control and go to Settings > TV Signal & Quality > Synchronise Picture & Sound, then select the appropriate value.

5. System information

Device information This option tells you the manufacturer, model and serial number of your YouView box. You may need this if your YouView box has a fault.

Software version This option tells you which versions of software you currently have installed. This will change from time to time as YouView updates software on vour behalf.

Number of channels This tells you how many channels you have tuned. Check here if you think you have missing channels.

TV signal quality In YouView, if you're having reception problems, you can check the quality and strength of the channel you're watching. In Settings, use the arrow key to scroll right to the TV Signal & Quality option, then press OK.

Network connection status This setting will show you the status of your connection. It will also give you information about that connection, such as the IP address. You can change this information in Network and Internet settings.



Waste Electrical & Electronic Equipment

Each year in the UK we throw away over 1.2 million tonnes of electrical and electronic waste (WEEE). Over 75% of this waste finishes up in landfill, where lead and other toxins can cause soil and water contamination. This can have a harmful effect on natural habitat. wildlife and also human health.

Many of the electrical items that we throw away can be recycled and re-used. Recycling helps to save natural finite resources and also reduces the environmental and health risks. EU and UK regulations require us to collect as much WEEE as possible for treatment, recovery/re-use and environmentally sound disposal.

You can play an important part by ensuring that your TalkTalk equipment is recycled or given to a take-back scheme... not just thrown away. Please visit talktalk.co.uk/weeereturns for details of the TalkTalk take-back scheme.

Quick connection

If you need to move things around in your home, simply follow the instructions to get set up easily.

1. Connect your TalkTalk router to the YouView box


using the grey Ethernet cable

2. Connect your TV to the YouView box

using the HDMI cable OR using the SCART cable

3. Connect the aerial to vour YouView box

using your existing aerial cable OR using the white aerial cable supplied 4. Connect the power cable and switch on



YouView service requires a broadband connection. YouView service subject to terms of use and suitable broadband speed, TV aerial and coverage, see youview.com for details. The YouView logo is a registered trade mark owned by YouView TV Limited and used under licence.

Rent the latest

Blockbusters and family films









Search for TalkTalk Box Office in The TalkTalk Player