


BLUETOOTH SPEAKER WITH QI CHARGING



MODEL: 347228

USER MANUAL



Goodmans

1 Welcome



2 Your Bluetooth Speaker with Qi Charging

2.1 In The Box

2.2 Front View

2.3 Back View

3 Quick Setup

3.1 AC Power Operation

3.2 Pairing With a Bluetooth Device

3.3 Playing Your Music

3.4 Using The LINE IN Connection

3.5 Charging Your Wireless iPhone, Smart Phone

3.6 Do's and Don'ts

4 Troubleshooting

5 Technical Specifications

6 Customer Support

1 Welcome



Thank you for choosing this Goodmans product. We have been making electrical products for the British people for over 90 years. Each of our products have been carefully designed to be great at what they do and this one is no exception. We hope you enjoy your Bluetooth Speaker with Qi Charging.

2 Your Bluetooth Speaker with Qi Charging

2.1 In The Box

Carefully remove your Bluetooth Speaker from the box.
Inside the box you will find:

- Bluetooth Speaker
- Line-in Cable
- DC 5V Adapter
- Quick Start Guide
- Instruction Manual
- Safety & Guarantee Leaflet



2.2 Front View

A Previous Track / Decrease Volume

Press the button to switch to the previous track.
Press and hold the button to decrease the volume.

B Play / Answer Calls / End Calls / Refused Calls / Redial Last Calls

When receiving a call. Press and hold the button to refuse a call.

A short press will play / answer / end a call.
Press the button twice to redial the last call.

C Wireless Charging Location

Used to charge your device.

D Pause

A short press will pause music.
Long press the button to change the input mode between Bluetooth and Line In.

E Next Track / Increase Volume

Press the button to switch to the next track.
Press and hold the button to increase the volume.


F LED Indicator Light

G MIC

H Speakers

I Wireless Charger LED Indicator Light

The device is being charged when the light is red and fully charged when the red LED is off.





2.3 Back View

J DC in Socket


Used to connect the speaker to the mains power supply.

K Line in Input

Used to connect the speaker to devices without Bluetooth.

L Power ON/OFF Switch

Switch power ON/OFF button to On or Off.




3 Quick Setup




3.1 AC Power Operation

1. Plug the mains lead into the DC 5V 2A socket located at the back of your speaker.
2. Plug the other end of the mains lead into a wall socket and switch on the wall socket.



3.2 Pairing With a Bluetooth Device

1. Switch the power ON/OFF button to the ON position; you will hear “Bluetooth mode, pairing”.



2. Using your Bluetooth phone or tablet, turn on Bluetooth and search for Bluetooth devices.
3. Enable Bluetooth on your Smartphone and search for Bluetooth connections, select “GOODMANS BT CHARGE” from the list of devices, if you are asked for pass code enter “0000”.
4. When successfully paired, you will hear “connected”.
5. Once you have paired the speaker with a Smartphone, the speaker will remember this device and will pair automatically when the device’s Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.
6. The speaker will attempt to automatically connect to the last device it was paired with if Bluetooth mode is turned on. If you want to pair it with a new device, please turn off your last Bluetooth device and then use your new device to search and select the pairing name.




3.3 Playing Your Music

When your Smartphone phone or tablet is paired to the speaker, use your music app to playback your music.

3.4 Using the line in Connection


1. If you device doesn't have Bluetooth, you can use the line in connection.
2. Connect the line in cable to the Bluetooth Speaker and connect the other end to your device.
3. Select your music on your device and play.

Note: When a Line In cable is connected your bluetooth speaker will disconnect from your Bluetooth device.



3.5 Charging Your Wireless iPhone, Smart Phone

1. Put your Qi enabled smart phone, on the centre of the charging location.
2. When the RED LED is on your device is charging.





3.6 Charging Do's and Don'ts

Keep away from devices with magnetic stripe or chip (ID cards, bank cards, etc.).

Keep at least 20cm/8 in away from medical implants to avoid interference.

Phone cases more than 0.5cm/0.2 in thick will prevent the charger from working properly. Please remove before charging.

Do not charge your phone in a metal case. Please remove before charging.

When your smartphone is fully charged we recommend that it is removed from the charging base.

4 Troubleshooting

Problem	What to do
Bluetooth speaker does not switch on.	Connect the unit to the power supply.
I can't pair the speaker with my Bluetooth device.	Turn on the speaker. Make sure that the LINE IN cable is not connected. Make sure that the LED indicator light is brightness.
I can't hear my music.	Turn the Bluetooth speaker ON. Using the volume control on your device to turn the volume up.
My device keeps on disconnecting from the Bluetooth speaker.	Make sure the Bluetooth speaker is connected to the power supply. If the LINE IN cable is connected, remove it. Make sure that your device is not further than 10 meters away from the Bluetooth Speaker.
My phone is not charging.	Make sure that the phone is positioned correctly on the wireless charger. If the phone is in a case, remove it and try again. Check the manual supplied with your phone to make sure that it is Qi compatible.

5 Technical Specifications



Model Number	347228
Bluetooth Specification	Bluetooth V 5.0
Bluetooth Operating Distance	10 meters (max.)
Frequency Response	100Hz~18KHz
External Power Supply	DC 5V 2A
Speaker Power	2 x 10W
Wireless Output	DC 5V/1A
Product Size	28*13.5*15cm

6 Customer Support



This product is Intended for use within the UK.

This appliance complies with the below listed EU directives

2014/30/EU Electromagnetic Compatibility Directive

2014/35/EU Low Voltage Directive

2011/65/EU Restriction of Hazardous Substances Directive

2014/53/EU Radio Equipment Directive

2009/125/EC Eco-design Directive

The complete declaration of conformity is available upon request for relevant enquiries.

 **Bluetooth**[®] is a trademark on a registered trademark of Bluetooth SIG Inc.

The "Qi" symbol is a trademark of the wireless power consortium.

Information on Waste Disposal for Consumers of Electrical & Electronic Equipment



This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used.

For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge.

If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be helping to save valuable resources and preventing any potential negative effects upon human health and the environment, of any hazardous materials that the waste may contain.

